

PULL-UP SCREEN (PS)

OPERATION GUIDE

INSTALLATION

The screen doesn't need installation, it can be used at once. Just place it on the floor and use.

USE

When using the screen, pull out the two supporting legs under the cassette to stabilize the screen, open up the cassette and pull up the screen to desired height by using the handle. The height can easily be adjusted by pressing or pulling the handle.

To keep your screen in good condition, always retract the screen back into the cassette after use. Do not expose the screen to direct sunlight or high temperatures.

Initially, there might be small waves on the surface of the screen. These are due to changes in humidity during transport, and normally most of them disappear within a few days. However, screen fabric rolled up on an axle is seldom entirely free from waves.

CARE

Use a moist cotton cloth to clean the screen surface. Do not use strong chemicals.

SERVICE AND SUPPORT

Look at our webpage www.kingpinscreens.com under contact for possible service. Keep the original packing of the screen for any future service.